

Full bore cast iron ball valve PN10/16 flanges with ATEX approved, CE marked and stainless steel ball and stem. Perfect for Biogas applications.


Spec	ifications:
1	Body is Cast Iron
2	Suits PN10/16 flanges
3	PTFE seats
4	Viton seal
5	1/2" to 8"
6	Iso pad—not direct mount, needs bracket
7	-10 to +200C
8	Stocked in Europe







## VALVE SIZE ( in mm ) :



Ref.	DN	15	20	25	32	40	50	65	80	100	125	150	200
	ØP	13	17	24	31	38	50	65	80	100	125	150	200
	L	115	120	125	130	140	150	170	180	190	200	210	400
	L1	49	55.5	51.5	53	61	62	81.5	79	94	120.5	155	190
507	н	92	95.5	102.2	114.7	119	127	141	151.5	176.5	208	254.5	293.5
	H1	48.5	53	59.5	72	77	85	98	108.5	134	165	190	229
	E	170	170	170	170	302.5	302.5	335	335	350	350	500	500
	Weight ( Kg )	2.12	2.72	3.62	5.32	6.9	9	11.68	14.68	20.23	33.73	49.77	81.77


Tel: 01386 552369

Fax: 01386 554227

sales@allvalves.co.uk



### MATERIALS:



ltem	Designation	Materials
1	Body	Cast iron EN GJL-250
2	Ends	Cast iron EN GJL-250
3	Solid Ball DN 15 - 25	SS 303
3	Hollow Ball DN 32 - 200	SS 304
4	Stem	SS 304
5	Seat	PTFE
6	Handle	Steel
12	Washer	PTFE
13	Body gasket	PTFE
15	Body screw	Steel DIN 933 5.6
16	Handle screw	Steel DIN 933 5.6
17	Handle washer	Steel
72	O ring	FKM
471	Circlip	Steel DIN 471
912	Stop Screw	Steel DIN 912 8.8



# **CAST IRON BALL VALVE PN 16**

#### SPECIFICATIONS:

- Full bore
- · Anti blow-out stem
- · With O ring FKM on stem and PTFE washer
- ISO 5211 mounting pad
- PN10/16 Flanges R.F. up to DN150 and PN16 for DN200 ( Threaded holes flanges for DN 125 and 150 )
- . Solid stainless steel ball up to DN 25, hollow ball from DN 32 to DN 200
- · Black painting colour RAL 9004 5-15 microns thickness

### USE:


- · For all common fluids
- . Min and max Temperature Ts: 10°C to + 200°C
- . Max Pressure Ps: 16 bars
- · Do not use with steam
- · Do not use with compressed air

## RANGE:

Cast iron flanges R.F. with s.s. ball PN10/16 from DN15 to DN150 and PN16 for DN200 Ref. 507 from DN 15 to DN 200

### PRESSURE / TEMPERATURE GRAPH ( STEAM EXCLUDED ) :





### FLOW COEFFICIENT Kvs (in M3/H);


DN	15	20	25	32	40	50	65	80	100	125	150	200
Kvs (M3 / H)	37.4	74.8	105	176	223	416	660	1200	1980	3600	5040	10890

Tel: 01386 552369 Fax: 01386 554227 sales@allvalves.co.uk



# **CAST IRON BALL VALVE PN 16**

# STEM AND ISO MOUNTIG PAD SIZE (in mm):



Ref.	DN	15	20	25	32	40	50	65	80	100	125	150	200
	ØK	42	42	42	42	42	42	70	70	70	70	102	102
	ISO	F04	F04	F04	F04	F04	F04	F07	F07	F07	F07	F10	F10
	N x Ø Z	4 x 5	4 x 5	4 x 5	4 x 5	4 x 5	4 x 5	4 x 8	4 x 8	4 x 8	4 x 8	4 x 10	4 x 10
507	C	7	7	7	7	12	12	13	13	16	16	20	20
307	ØY	10	10	10	10	16	16	18	18	22	22	28	28
	Н3	5.5	5	5	5.5	16	16	19	19	20	20	27	27
	H4	7.5	6	6.2	6.7	15	15	18	18	19	19.5	24.5	24.5
	ØA	19	19	21	21	30	30	35	35	38	38	50	50

Tel: 01386 552369

Fax: 01386 554227

sales@allvalves.co.uk



# **ALLVALVES SERIES 168 - ATEX CAST IRON BALL VALE**

www.allvalves.co.uk

# CAST IRON BALL VALVE PN 16

#### TORQUE VALUES (in Nm without safety coefficient):

DN	15	20	25	32	40	50	65	80	100	125	150	200
Torque ( Nm )	6	6	11	12	26	41	41	71	119	190	220	450

### STANDARDS:

- Fabrication according to ISO 9001 :2008
- DIRECTIVE 97/23/CE: Risk Category I module A from DN65 to DN200
- Valve design according to DIN 3357
- Body design according to DIN 3840
- ISO 5211 mounting pad
- Length according to EN 558 series 27 ( DIN 3202 F18 ) from DN 15 to 100 and for DN200
- Length according to EN 558 series 14 from DN 15 to 150
- Flanges R.F according to EN 1092-2 PN10/16
- Marking according to EN 19
- Pressure tests according to EN 12266-1
- ATEX Group II Category 2 G/2Dc Zone 1 & 21 Zone 2 &22 (optional marking)

**ADVICE**: Our opinion and our advice are not guaranteed and SFERACO shall not be liable for the consequences of damages. The customer must check the right choice of the products with the real service conditions.



## INSTALLATION INSTRUCTIONS

### **GENERAL GUIDELINES:**

- Ensure that the valves to be used are appropriate for the conditions of the installation (type of fluid,pressure and temperature).
- Be sure to have enough valves to be able to isolate the sections of piping as well as the appropriate equipment for maintenance and repair.
- Ensure that the valves to be installed are of correct strength to be able to support the capacity of their usage.
- Installation of all circuits should ensure that their function can be automatically tested on a regular basis (at least two times a year).

### **INSTALLATION INSTRUCTIONS:**

- Before installing the valves, clean and remove any objects from the pipes (in particular bits of sealing and metal) which could obstruct and block the valves.
- Ensure that both connecting pipes either side of the valve (upstream and downstream) are aligned (if they're not, the valves may not work correctly).
- Make sure that the two sections of the pipe (upstream and downstream) match, the valve unit will
  not absorb any gaps. Any distortions in the pipes may affect the thightness of the connection, the
  working of the valve and can even cause a rupture. To be sure, place the kit in position to ensure the
  assembling will work.
- If sections of piping do not have their final support in place, they should be temporarily fixed. This is to avoid unnecessary strain on the valve.
- Tighten the bolts in cross.
- . It's recommended to operate the valve (open and close) 1 to 2 times per year

Tel: 01386 552369 Fax: 01386 554227 sales@allvalves.co.uk